

**⚠ WARNING! READ ⚠
BEFORE INSTALLATION**

1. GENERAL:

A failure resulting in injury or damage may be caused by excessive overpressure, excessive vibration or pressure pulsation, excessive instrument temperature, corrosion of the pressure containing parts, or other misuse. Consult Ashcroft Inc., Stratford, Connecticut, USA before installing if there are any questions or concerns.

2. OVERPRESSURE:

Pressure spikes in excess of the rated overpressure capability of the transducer may cause irreversible electrical and/or mechanical damage to the pressure measuring and containing elements.

Fluid hammer and surges can destroy any pressure transducer and must always be avoided. A pressure snubber should be installed to eliminate the damaging hammer effects. Fluid hammer occurs when a liquid flow is suddenly stopped, as with quick closing solenoid valves. Surges occur when flow is suddenly begun, as when a pump is turned on at full power or a valve is quickly opened.

Liquid surges are particularly damaging to pressure transducers if the pipe is originally empty. To avoid damaging surges, fluid lines should remain full (if possible), pumps should be brought up to power slowly, and valves opened slowly. To avoid damage from both fluid hammer and surges, a surge chamber should be installed.

Symptoms of fluid hammer and surge's damaging effects:

- Pressure transducer exhibits an output at zero pressure (large zero offset).
- Pressure transducer output remains constant regardless of pressure
- In severe cases, there will be no output.

FREEZING:

Prohibit freezing of media in pressure port. Unit should be drained (mount in vertical position with electrical termination upward) to prevent possible overpressure damage from frozen media.

3. STATIC ELECTRICAL CHARGES:

Any electrical device may be susceptible to damage when exposed to static electrical charges. To avoid damage to the transducer observe the following:

- Ground the body of the transducer **BEFORE** making any electrical connections.
- When disconnecting, remove the ground **LAST!**


Note: The shield and drain wire in the cable (if supplied) is not connected to the transducer body, and is not a suitable ground.

Mounting

Although the unit can withstand normal vibration without damage or significant output effects, it is always good practice to mount the transducer where there is minimum vibration.

Power Supply

The supply voltage for the 1-5 and 1-6 Vdc output transducers must be within the range of 10 to 36 Vdc. The maximum supply voltage for a 4-20mA current output transducer is 36 Vdc while the minimum supply voltage is dependent upon the loop resistance of the circuit. The figure below shows the minimum supply voltage (V_{min}) required for a given loop resistance (R_{LOOP}).



Noise

For minimum noise susceptibility, avoid running the transducer's cable in a conduit that contains high current ac power cables. Where possible avoid running the cable near inductive equipment.

Shield Wiring

Connect the braided shield to the guard terminal on the reading instrument (meter, etc.) if available or to ground or to the power supply negative terminal.

Adjustment Potentiometers

The zero and span pots are accessible through the top of the case. Loosen the collar and separate the top carefully. The zero pot is marked with a white dot.

Vent Tube


The cable will have a clear Teflon vent tube that's required at pressure below 500 psi to provide atmospheric reference. The open end should be placed in a dry area.

**MODEL KX THIN FILM
PRESSURE TRANSDUCER
INSTRUCTION SHEET**



KX Series – Electrical Connections

Voltage Output Units 1-5, 1-6 Vdc



Cable Type C1

Red = + Power
Black = Common
White = Output



DIN Type

PIN-1 = + Power
PIN-2 = Common
PIN-3 = Output

Current Output Units 4-20mA



Cable Type C1



Red = + Power
Black = - Power



DIN Type

PIN-1 = + Power
PIN-2 = - Power

KX Series – Wiring Diagrams



KX Series – Recalibration Instructions

1. Apply 0% Full Scale Pressure.
2. Set the output using the Zero adjustment potentiometer.
3. Apply 100% Full Scale Pressure.
4. Set the output using the Span adjustment potentiometer.
5. Repeat steps 1 thru 4 as necessary.

KX Series Dimensions

